
5. Install tube cover from the backside of the mounting bracket. Secure AG110-003 in mounting bracket and tube cover with provided mounting screws (See Fig 1-5).

6. Connect 1/4-inch OD poly tubing from an RO unit to the AG110-003 inlet port. Connect 3/8-inch OD poly tubing to the outlet port and insert the other end into a drain pipe through a drain pipe adapter. (See FIG 1-6)



7. Apply decorative cover over wall mount bracket. For dimensions, see FIG 1-7.



Copyright @ AIRGAP INTERNATIONAL a Division of Altinex Inc.

+#6 Mounting Screw

#8 Mounting Screws

-Tubing cover

#6 Mounting Screw

Fig 1-5






Placentia, California



Model: AG110-003

REVERSE OSMOSIS AIR GAP DRAIN 1/4" INLET PORT 3/8" OUTLET PORT

(Maximum flow rate 1.0 GPM)



Old Part Number: GAP-A-RO, KIT S-C

Doc.#400-0808-002

AG110-003

Installation Procedures

LIST OF PARTS ENCLOSED 1- Reverse Osmosis Air Gap in Wall Mount Bracket 1- Decorative Cover 1- Tube Mold Cover 3- #8-1", Phillips Pan Head Screws 3- #6-1", Phillips Pan Head Screws

The AG110-003 Reverse Osmosis Filter Air Gap prevents back-flow from the discharge line into the RO system. The discharge water flows out of the reverse osmosis system into the air gap inlet, passes air-gap, and then down to the drain piping.

- Secure connection of inlet and outlet ports.
- Tested for maximum 1GPM (3.8 Liters/minute)
- Suggested flow rate 1 to 16 oz/minute (30 to 500 milliliters/minute)
- UPC® listed, tested for compliance with IPC and NSF standards

Always comply with local plumbing codes during installation

Please read the instructions once through before starting.

AG110-003 INSTALLATION INSTRUCTION

1. Make sure that the flow rate output of the RO equipment meets AG110-003 flow capacity limits such as 0.4 GPM (1.5 Liters/minute).

2. Check inlet and outlet ports marking on AG110-003 body. AG110-003 provided installed in wall mount bracket FIG 1-1, for dimensions see FIG 1-2.

